Table of Contents

Sources	1
Reference	3

1/2

Sources

made of a perfect electric conductor.

Sample parameter file: total/scattered field source.

In scattered field (SF) formulation, we only add the plane wave on tangential electric field components of interface between conductor and non-conductor, simulating the fact that in real world there are currents cancelling the tangetial components of electromagnetic wave generated on such interface. At it's simplest variant this technique is therefore not suitable for dielectrics and it is used for calculations consisting of perfect electric conductors in a free space. However, comparing to TSF, it can provide more accurate results for scattering calculations in these cases.

GSvit documentation - http://www.gsvit.net/wiki/

If we need a plane wave to interact with our computation volume, we are no more able to use a set of point sources (unless we have extremely large computational volume which is unrealistic. Special techniques need to be used, for example one known as total/scattered field or scattered field. Both approaches are based on addition and eventually subtraction of precomputed plane wave to/from some points in the computational volume.

In total/scattered field (TSF) technique we draw a boundary around the area where we need the plane wave and we add the plane wave on one side and subtract it on other side (depending on wave traveling direction). There can be anything inside TSF volume as there are no special algorithms run there.

To perform a computation we need to setup at least single source of electromagnetic field. The simplest source is a point one, which is physically similar to a small dipole. More rigorous is an electric

Sample parameter file: point source.

or magnetic current source which has exactly the same functionality as the electric or magnetic dipole.

A 200x200x200 computational domain with total/scattered field source and a metallic sphere made of a perfect electric conductor.



Sample parameter file: scattered field source. A 200x200x200 computational domain with scattered field source and a metallic sphere made of a perfect electric conductor.



To get a focused source we can use plane waves summation method as published in Ref. [1]. This is based on decomposition of the ideal focused beam onto a set of plane wave with appropriate angles and phases.

Sample parameter file: total/scattered focused field source. A 200x200x200 computational domain with focused source and a metallic sphere made of a perfect electric conductor.



Layered source is a special source conditions suitable for materials with infinitely extending layers (e.g. thin films) as published in Ref. [2]. In our implementation the layers have to be laterally oriented in xy direction, so they have normal in z direction. The material can be formed by N layers in z-direction (in present implementation only dielectric and non-absorbing). Incident wave however can cross the sample at angle as well.



Sample parameter file: layers compatible field source. A 200x200x200 computational domain with source compatible with infinitely extending layers.



Layered focused source is a mixture of focused source plane wave summation and use of infinite layers in z direction, i.e. the above two sources.

Sample parameter file: layers compatible focused field source. A 200x200x200 computational domain with focused source compatible with infinitely extending layers. Sources

Reference

[1] I.R.Capoglu, A. Taflowe, V. Backman, Optics Express 23 (2008) 19208.

[2] I.R. Capoglu, G.S. Smith: IEEE Transactions on Antennas and Propagation 02/2008, 56:1.

From: http://www.gsvit.net/wiki/ - GSvit documentation Permanent link: http://www.gsvit.net/wiki/doku.php/fdtd:sources?rev=1535303240 Last update: 2018/08/26 19:07